Operating instructions

Doors, fittings and everyday use – WESSELER W-LINIE 2

YOUR INSTALLATION AT A GLANCE

Fixed area:	laminated safety glass, pane to pane with a 2 mm butt joint, guided top and bottom in the wall and floor profile.
Door:	glass or timber door leaf in a system frame, held at the sides by posts.
Transom light:	above the door, closing the installation up to the ceiling.
Profiles:	aluminium, powder-coated in the chosen RAL colour.

OPERATING THE DOOR

- **Open and close gently.** Do not slam the door or throw it against the stop.
- **Always guide it by the handle,** never push on the glass edge or the leaf itself.
- **Double doors:** lock the passive leaf first, then close the active leaf.
- **Lock:** insert the key fully and turn without force. If it catches, press the door to slightly and turn again.
- **Use hold-open devices and door stops** only where they are fitted – never wedge the door open with objects.

IN EVERYDAY USE

- **Lean nothing against it:** no ladders, furniture, pallets or tools against glass or profiles.
- **Hang nothing from it:** fittings, handles and profiles are not designed to carry loads.
- **Do not hang on or lean against an open leaf** – not even briefly.
- **Keep the passage clear:** no cables, carpet edges or boxes within the swing area.
- **During work in the room** cover the glass surfaces – drilling dust, paint and sparks damage glass and coating.

Operating instructions – safety and faults

What you can do yourself and when we come out

SAFETY

- **Laminated safety glass:** does not break into sharp pieces but stays bonded to the interlayer. Still report a cracked pane at once and stop loading it.
- **Mark large glass areas:** where people walk briskly, a visibility strip or lettering at eye level helps.
- **Children:** doors are not play equipment – fingers do not belong in the gap between leaf and frame.
- **Escape routes:** doors in escape and rescue routes must be openable at all times without aids.
- **After an impact** check the pane in backlight: fine cracks at the edge are how damage starts.

IF SOMETHING STICKS

- **Door drags on the floor:** check the floor area for dirt and clean it. If that does not help, the hinge needs adjusting – please tell us.
- **Door does not close fully:** check whether something is caught in the rebate. Never force it shut.
- **Lock catches:** do not force the key. We will adjust the lock.
- **Handle feels loose:** do not tighten it yourself – the screw can stress the glass.
- **Creaking or whistling:** usually a draught or a seal. One call is enough and we will look at it.

ONCE A YEAR

Walk through the installation once a year: does every door move smoothly and close cleanly? Are handles and hinges firmly seated? Are the seals undamaged? Is the floor profile clear? Whatever you notice, we adjust during a service visit. Adjustment and replacement belong in professional hands – that is what keeps the installation sound.

QUESTIONS OR DAMAGE?

If something is damaged, a door sticks or you have a question about care, we help quickly and without fuss. Innenausbau Wesseler · Lise-Meitner-Straße 11a · 46325 Borken, Germany · Phone +49 2861 929753 · mw@mwesseler.com

> WESSELER W-LINIE 2 is our in-house type designation for this range. It is not a test or approval mark. These instructions apply to installations we manufactured and fitted ourselves.